

The logo consists of a red rounded square containing the text "TQSDT" in white, bold, sans-serif capital letters.

**TQSDT**

# **SERVICE MANUAL**

## **MODELS:**

TM18H4O

TM24H4O

## Table of Contents


<b>Part I : Technical Information</b>	1
1. Summary	1
2. Specifications	2
3. Outline Dimension Diagram	10
4. Refrigerant System Diagram	11
5. Electrical Part	12
5.1 Wiring Diagram	12
5.2 PCB Printed Diagram	14
6. Function and Control	16
<b>Part II : Installation and Maintenance</b>	19
7. Notes for Installation and Maintenance	19
8. Installation Manual	21
8.1 Electrical Connections	22
8.2 Installing the Outdoor Unit	23
8.3 Installation Dimension Diagram	24
8.4 Check after Installation	25
9. Troubleshooting	26
9.1 Flashing LED of Indoor/Outdoor Unit and Primary Judgement	26
9.2 Malfunction Checking and Elimination	27
9.3 Maintenance Method for Normal Malfunction	40
10. Exploded View and Parts List	42
11. Removal Procedure	48
<b>Appendix:</b>	61
Appendix 1: Reference Sheet of Celsius and Fahrenheit	61
Appendix 2: Configuration of Connection Pipe	61
Appendix 3: Pipe expanding method	62
Appendix 4: List of Resistance for Temperature Sensor	63

# Part I : Technical Information


## 1. Summary

### Outdoor Unit

GWHD(18)ND3EO  
GWHD(18)ND3FO  
TM18H4O



GWHD(24)ND3EO  
GWHD(24)ND3FO  
TM24H4O



## 2. Specifications

Model			1.GWHD(18)ND3EO 2.GWHD(18)ND3FO
Product Code			1.CB228W04100 2.CB228W07600
Power supply	Rated Voltage	V~	208/230
	Rated Frequency	Hz	60
	Phases		1
Cooling capacity(max~min)		W	5280(2051~6155)
Heating capacity(max~min)		W	5570(2500~6624)
Cooling Power Input(max~min)		W	1650
Heating Power Input(max~min)		W	1640
Cooling Current Input		A	10.67/10.56
Heating Current Input		A	6.78/6.10
Rated Power Input		W	2800
Rated Current		A	12.48
EER		W/W	3.2
COP		W/W	3.4
Outdoor Unit	Compressor Trademark		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXA-B141zF030A
	Compressor Refrigerant Oil Type		RB68EP
	Compressor Type		Inverter Rotary
	L.R.A	A	25
	Compressor Rated Load Amp (RLA)	A	10.82
	Compressor Power Input	W	1440
	Compressor Thermal Protector		1NT11L-6233/KSD115°C /HPC115/95U1
	Throttling Method		Electron expansion valve
	Cooling Operation Ambient Temperature Range	°F	-0.4~118.4
	Heating Operation Ambient Temperature Range	°F	-4~75.2
	Condenser Material		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	inch	Φ9/32
	Rows-Fin Gap(mm)	inch	2-1/18
	Coil length (l) X height (H) X coil width (L)	inch	33 1/2X1 /12X26
	Fan Motor Speed (rpm) (H/M/L)	rpm	630
	Output of Fan Motor	W	60
	Fan Motor RLA	A	0.62
	Fan Motor Capacitor	μF	/
	Air Flow Volume of Outdoor Unit	CFM	1883
	Fan Type-Piece		Axial-flow
	Fan Diameter	inch	Φ20 1/2
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Dimension (W/H/D)	inch	38X27 9/16X15 39/64
	Dimension of Package (L/W/H)	inch	40 13/32X18X29
	Dimension of Package(L/W/H)	inch	40 1/2X18X29 1/2
	Net Weight	lb	114.7
	Gross Weight	lb	124.6
	Refrigerant Charge		R410A
	Refrigerant Charge	oz	56.45



Outdoor Unit	Cross-sectional Area of Power Cable Conductor	sq in	0.0032
	Recommended Power Cable(Core)	N	3
	Connection Pipe Connection Method		Flare Connection
	Not Additional Gas Connection Pipe Length	ft	16.4
	Connection Pipe Gas Additional Charge	oz/ft.	0.2
	Outer Diameter of Liquid Pipe1(GREE Allocation) (Metric)	inch	1/4
	Outer Diameter of Liquid Pipe2(GREE Allocation) (Metric)	inch	1/4
	Outer Diameter of Gas Pipe1(GREE Allocation) (Metric)	inch	3/8
	Outer Diameter of Gas Pipe2(GREE Allocation) (Metric)	inch	3/8
	Connection Pipe Max. Height Distance(indoor and indoor)	ft	32.8
	Connection Pipe Max. Height Distance(indoor and outdoor and indoor up)	ft	32.8
	Connection Pipe Max. Height Distance(indoor and outdoor and outdoor up)	ft	32.8
	Max. equivalent connection pipe length(outdoor to last indoor)	ft	32.8
	Connection Pipe Max. Length Distance(total length)	ft	65.6

The above data is subject to change without notice; please refer to the nameplate of the unit.

Model			1.GWHD(24)ND3EO 2.GWHD(24)ND3FO
Product Code			1.CB228W04200 CB228W04203 2.CB228W07500
Power supply	Rated Voltage	V~	208/230
	Rated Frequency	Hz	60
	Phases		1
Cooling capacity(max~min)		W	7620(2198~9672)
Heating capacity(max~min)		W	8500(2198~7500)
Cooling Power Input(max~min)		W	2400
Heating Power Input(max~min)		W	2350
Cooling Current Input		A	10.65
Heating Current Input		A	10.43
Rated Power Input		W	4550
Rated Current		A	20.19
EER		W/W	3.0
COP		W/W	3.5
Outdoor Unit	Compressor Trademark		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXAS-D23zX090B
	Compressor Refrigerant Oil Type		RB68EP
	Compressor Type		Inverter Rotary
	L.R.A	A	/
	Compressor Rated Load Amp (RLA)	A	17
	Compressor Power Input	W	2550
	Compressor Thermal Protector		1NT11L-6233
	Throttling Method		Electron expansion valve
	Cooling Operation Ambient Temperature Range	°F	-0.4~118.4
	Heating Operation Ambient Temperature Range	°F	-4~75.2
	Condenser Material		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	inch	Φ2/7
	Rows-Fin Gap(mm)	inch	2-1/18
	Coil length (l) X height (H) X coil width (L)	inch	38 21/32X1 1/2X29 7/16
	Fan Motor Speed (rpm) (H/M/L)	rpm	800
	Output of Fan Motor	W	90
	Fan Motor RLA	A	0.59
	Fan Motor Capacitor	μF	/
	Air Flow Volume of Outdoor Unit	CFM	2354
	Fan Type-Piece		Axial-flow
	Fan Diameter	inch	Φ21 43/64-2 39/64
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Dimension (W/H/D)	inch	38 37/64X31 7/64X17 21/64
	Dimension of Package (L/W/H)	inch	42 1/2X19X33
	Dimension of Package(L/W/H)	inch	42 43/64X19 13/64X33 43/64
	Net Weight	lb	153.2
	Gross Weight	lb	164.3
	Refrigerant Charge		R410A
	Refrigerant Charge	oz	77.6

Outdoor Unit	Cross-sectional Area of Power Cable Conductor	sq in	0.0051
	Recommended Power Cable(Core)	N	3
	Connection Pipe Connection Method	-	Flare Connection
	Not Additional Gas Connection Pipe Length	ft	16.4
	Connection Pipe Gas Additional Charge	oz/ft.	0.2
	Outer Diameter of Liquid Pipe1(GREE Allocation) (Metric)	inch	1/4
	Outer Diameter of Liquid Pipe2(GREE Allocation) (Metric)	inch	1/4
	Outer Diameter of Liquid Pipe2(GREE Allocation) (Metric)	inch	1/4
	Outer Diameter of Gas Pipe1(GREE Allocation) (Metric)	inch	3/8
	Outer Diameter of Gas Pipe2(GREE Allocation) (Metric)	inch	3/8
	Outer Diameter of Gas Pipe2(GREE Allocation) (Metric)	inch	3/8
	Connection Pipe Max. Height Distance(indoor and indoor)	ft	32.8
	Connection Pipe Max. Height Distance(indoor and outdoor and indoor up)	ft	32.8
	Connection Pipe Max. Height Distance(indoor and outdoor and outdoor up)	ft	32.8
	Max. equivalent connection pipe length(outdoor to last indoor)	ft	65.6
	Connection Pipe Max. Length Distance(total length)	ft	196.8

The above data is subject to change without notice; please refer to the nameplate of the unit.

Model			TM18H40
Product Code			CB228W07700
Power supply	Rated Voltage	V~	208/230
	Rated Frequency	Hz	60
	Phases		1
Cooling capacity(max~min)		Btu/h	18000(6155~6998)
Heating capacity(max~min)		Btu/h	19000(8530~22600)
Cooling Power Input(max~min)		W	1440
Heating Power Input(max~min)		W	1520
Cooling Current Input		A	6.26
Heating Current Input		A	6.61
Rated Power Input		W	2800
Rated Current		A	12.42
EER		(Btu/h)/W	12.5
COP		(Btu/h)/W	12.5
Outdoor Unit	Compressor Trademark		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXA-B141zF030A
	Compressor Refrigerant Oil Type		RB68EP
	Compressor Type		Inverter Rotary
	L.R.A	A	/
	Compressor Rated Load Amp (RLA)	A	10.82
	Compressor Power Input	W	1440
	Compressor Thermal Protector		1NT11L-6233
	Throttling Method		Electron expansion valve
	Cooling Operation Ambient Temperature Range	°F	-0.4~118.4
	Heating Operation Ambient Temperature Range	°F	-4~75.2
	Condenser Material		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	inch	Φ9/32
	Rows-Fin Gap(mm)	inch	2-1/18
	Coil length (l) X height (H) X coil width (L)	inch	33 1/2X1 /12X26
	Fan Motor Speed (rpm) (H/M/L)	rpm	630
	Output of Fan Motor	W	60
	Fan Motor RLA	A	0.62
	Fan Motor Capacitor	μF	/
	Air Flow Volume of Outdoor Unit	CFM	1883
	Fan Type-Piece		Axial-flow
	Fan Diameter	inch	Φ20 1/2
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Dimension (W/H/D)	inch	38X27 9/16X15 39/64
	Dimension of Package (L/W/H)	inch	40 13/32X18X29
	Dimension of Package(L/W/H)	inch	40 1/2X18X29 1/2
	Net Weight	lb	114.7
	Gross Weight	lb	124.6
	Refrigerant Charge		R410A
	Refrigerant Charge	oz	56.45

Outdoor Unit	Cross-sectional Area of Power Cable Conductor	sq in	0.0032
	Recommended Power Cable(Core)	N	3
	Connection Pipe Connection Method		Flare Connection
	Not Additional Gas Connection Pipe Length	ft	32.8
	Connection Pipe Gas Additional Charge	oz/ft.	0.2
	Outer Diameter of Liquid Pipe1(GREE Allocation) (Metric)	inch	1/4
	Outer Diameter of Liquid Pipe2(GREE Allocation) (Metric)	inch	1/4
	Outer Diameter of Gas Pipe1(GREE Allocation) (Metric)	inch	3/8
	Outer Diameter of Gas Pipe2(GREE Allocation) (Metric)	inch	3/8
	Connection Pipe Max. Height Distance(indoor and indoor)	ft	32.8
	Connection Pipe Max. Height Distance(indoor and outdoor and indoor up)	ft	32.8
	Connection Pipe Max. Height Distance(indoor and outdoor and outdoor up)	ft	32.8
	Max. equivalent connection pipe length(outdoor to last indoor)	ft	32.8
	Connection Pipe Max. Length Distance(total length)	ft	65.6

The above data is subject to change without notice; please refer to the nameplate of the unit.


Model			TM24H4O
Product Code			CB228W07800
Power supply	Rated Voltage	V~	208/230
	Rated Frequency	Hz	60
	Phases		1
Cooling capacity(max~min)		Btu/h	24000(7500~33000)
Heating capacity(max~min)		Btu/h	26000(7500~35000)
Cooling Power Input(max~min)		W	1920
Heating Power Input(max~min)		W	2050
Cooling Current Input		A	8.35
Heating Current Input		A	8.9
Rated Power Input		W	4550
Rated Current		A	20.19
EER		(Btu/h)/W	12.5
COP		(Btu/h)/W	12.7
Outdoor Unit	Compressor Trademark		ZHUHAI LANDA COMPRESSOR CO.,LTD
	Compressor Model		QXAS-D23zX090B
	Compressor Refrigerant Oil Type		RB68EP
	Compressor Type		Inverter Rotary
	L.R.A	A	/
	Compressor Rated Load Amp (RLA)	A	15.82
	Compressor Power Input	W	2550
	Compressor Thermal Protector		1NT11L-6233
	Throttling Method		Electron expansion valve
	Cooling Operation Ambient Temperature Range	°F	-0.4~118.4
	Heating Operation Ambient Temperature Range	°F	-4~75.2
	Condenser Material		Aluminum Fin-copper Tube
	Condenser Pipe Diameter	inch	Φ2/7
	Rows-Fin Gap(mm)	inch	2-1/18
	Coil length (l) X height (H) X coil width (L)	inch	38 21/32X1 1/2X29 7/16
	Fan Motor Speed (rpm) (H/M/L)	rpm	800
	Output of Fan Motor	W	90
	Fan Motor RLA	A	0.59
	Fan Motor Capacitor	μF	/
	Air Flow Volume of Outdoor Unit	CFM	2354
	Fan Type-Piece		Axial-flow
	Fan Diameter	inch	Φ21 43/64-2 39/64
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IPX4
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Dimension (W/H/D)	inch	38 37/64X31 7/64X17 21/64
	Dimension of Package (L/W/H)	inch	42 1/2X19X33
	Dimension of Package(L/W/H)	inch	42 43/64X19 13/64X33 43/64
	Net Weight	lb	153.2
	Gross Weight	lb	164.3
	Refrigerant Charge		R410A
	Refrigerant Charge	oz	77.6

Outdoor Unit	Cross-sectional Area of Power Cable Conductor	sq in	0.0051
	Recommended Power Cable(Core)	N	3
	Connection Pipe Connection Method	-	Flare Connection
	Not Additional Gas Connection Pipe Length	ft	98.4
	Connection Pipe Gas Additional Charge	oz/ft.	0.2
	Outer Diameter of Liquid Pipe1(GREE Allocation) (Metric)	inch	1/4
	Outer Diameter of Liquid Pipe2(GREE Allocation) (Metric)	inch	1/4
	Outer Diameter of Liquid Pipe2(GREE Allocation) (Metric)	inch	1/4
	Outer Diameter of Gas Pipe1(GREE Allocation) (Metric)	inch	3/8
	Outer Diameter of Gas Pipe2(GREE Allocation) (Metric)	inch	3/8
	Outer Diameter of Gas Pipe2(GREE Allocation) (Metric)	inch	3/8
	Connection Pipe Max. Height Distance(indoor and indoor)	ft	32.8
	Connection Pipe Max. Height Distance(indoor and outdoor and indoor up)	ft	32.8
	Connection Pipe Max. Height Distance(indoor and outdoor and outdoor up)	ft	32.8
	Max. equivalent connection pipe length(outdoor to last indoor)	ft	65.6
	Connection Pipe Max. Length Distance(total length)	ft	196.8


The above data is subject to change without notice; please refer to the nameplate of the unit.

### 3. Outline Dimension Diagram

GWHD(18)ND3EO GWHD(18)ND3FO TM18H4O




GWHD(24)ND3EO GWHD(24)ND3FO TM24H4O





## 4. Refrigerant System Diagram



**A1:A-unit electronic expansion valve    B1:B-unit electronic expansion valve**  
**C1:C-unit electronic expansion valve    D1:D-unit electronic expansion valve**  
**A2:A-unit gas pipe temperature sensor    B2:B-unit gas pipe temperature sensor**  
**C2:C-unit gas pipe temperature sensor    D2:D-unit gas pipe temperature sensor**  
**A3:A-unit liquid pipe temperature sensor    B3:B-unit liquid pipe temperature sensor**  
**C3:C-unit liquid pipe temperature sensor    D3:D-unit liquid pipe temperature sensor**

## 5. Electrical Part


### 5.1 Wiring Diagram

#### ● Instruction


Symbol	Symbol Color	Symbol	Symbol Color	Symbol	Name
WH	White	GN	GREEN	COMP	Compressor
YE	Yellow	BN	Brown		Grounding wire
RD	Red	BU	Blue		
YEGN	Yellow/Green	BK	Black		
VT	Violet	OG	Orange		

#### ● Outdoor Unit

GWHD(18)ND3EO GWHD(18)ND3FO TM18H4O



GWHD(24)ND3EO GWHD(24)ND3FO TM24H40




These circuit diagrams are subject to change without notice, please refer to the one supplied with the unit.




GWHD(24)ND3EO GWHD(24)ND3FO TM24H4O

● TOP VIEW



1	Terminal of compressor
2	Low pressure protection terminal
3	High pressure protection terminal
4	Overload protection terminal of compressor
5	Temperature sensor terminal of outdoor unit
6	Electric heating terminal of chassis
7	Electric heating terminal of compressor
8	Terminal of outdoor unit
9	Terminal of 4-way valve
10	Temperature sensor for liquid valve and gas valve for unit A
11	Temperature sensor for liquid valve and gas valve for unit B
12	Temperature sensor for liquid valve and gas valve for unit C
13	Temperature sensor for liquid valve and gas valve for unit D
14	Electronic expansion vale for unit A
15	Electronic expansion vale for unit C
16	Electronic expansion vale for unit B
17	Electronic expansion vale for unit D
18	Communication wire with indoor unit
19	Neutral wire for counication
20	Live wire
21	Neutral wire
22	Reactor wire 1
23	Reactor wire 2

● BOTTOM VIEW



## 6. Function and Control

### 1 Basic functions of the system

#### 1.1 Cooling Mode

##### 1.1.1 Cooling conditions and process:

If the compressor is in stop status and start the unit for cooling operation, when one of the indoor units reaches the cooling operation condition, the unit start cooling operation; in this case, the electronic expansion valve, the outdoor fan and the compressor start operation.

##### 1.1.2 Stop in cooling operation

##### 1.1.2.1 Compressor stops

The compressor stops immediately, the outdoor fan stops after 1min.

##### 1.1.2.2 Some of the indoor units reach the stop condition (the compressor does not stop)

The compressor operates immediately according to the required frequency. For the indoor unit with no requirement, the corresponding electronic expansion valve is closed to OP.

##### 1.1.3 Cooling mode transfers to heating mode

When the unit transfers to heating mode, the 4-way valve is energized after the compressor stops for 2min. The other disposals are the same as stopping in cooling mode.

##### 1.1.4 4-way valve: in this mode, the 4-way valve is closed.

##### 1.1.5 Outdoor fan control in cooling mode

The outdoor fan starts before 5s of the starting of compressor. The outdoor fan will run in high speed for 3min after starting and then it will run in set speed. The fan shall run at every speed for at least 80s. (When the quantity of running indoor unit is changed, the unit will enter the control described in 1.3.5.1 and 1.3.5.2);

When the compressor stops, the outdoor fan runs at present speed and stops after 1min.

#### 1.2 Dry Mode

##### 1.2.1 The dry conditions and process are the same as those in cooling mode;

##### 1.2.2 The status of 4-way valve: closed;

##### 1.2.3 The temperature setting range: 16 ~ 30℃;

##### 1.2.4 Protection function: the same as those in cooling mode;

##### 1.2.5 In dry mode, the maximum value A of the capacity requirement percentage of single unit is 90% of that in cooling mode.

The open condition of the electronic expansion valve, outdoor fan and compressor is the same as those in cooling mode.

#### 1.3 Heating Mode

##### 1.3.1 Cooling conditions and process:

When one of the indoor units reaches the heating operation condition, the unit starts heating operation.

##### 1.3.2 Stop in heating operation:

##### 1.3.2.1 When all the indoor units reach the stop condition, the compressor stops and the outdoor fan stops after 1min;

##### 1.3.2.2 Some of the indoor units reach the stop condition

The compressor reduces the frequency immediately and operates according to the required frequency;

##### 1.3.2.3 Heating mode transfers to cooling mode(dry mode), fan mode

a. The compressor stops; b. the power of 4-way valve is cut off after 2min; c. the outdoor fan stops after 1min; d. the status of 4-way valve: energized;

### 1.3.3 Outdoor fan control in heating mode

The outdoor fan starts before 5s of the starting of compressor and then it will run in high speed for 40s;

The fan shall run at every speed for at least 80s;

When the compressor stops, the outdoor fan stops after 1min.

### 1.3.4 Defrosting function

When the defrosting condition is met, the compressor stops; the electronic expansion valve of all indoor units open in big angle; the outdoor fan stops after 40s of the stop of compressor, meanwhile, the 4-way valve reverses the direction; after the 4-way valve reverses the direction, the compressor starts; then begin to calculate the time of defrosting, the frequency of the compressor rises to reach the defrosting frequency.

### 1.3.5 Oil-returned control in heating mode

#### 1.3.5.1 Oil-returned condition

The whole unit is operating in low frequency for a long time

#### 1.3.5.2 Oil-returned process in heating mode

The indoor unit displays "H1"

#### 1.3.5.3 Oil-returned finished condition in heating mode

The duration reaches 5min

## 1.4 Fan Mode

The compressor, the outdoor fan and the 4-way valve are closed; temperature setting range is 16~30℃.

## 2. Protection Function

### 2.1 Mode Conflict Protection of indoor unit

When the setting mode is different of different indoor unit, the unit runs in below status:

- a. The mode of the first operating indoor unit is the basic mode, then compare the mode of the other indoor units to see if there is a conflict. Cooling mode (dry mode) is in conflict with heating mode.
- b. Fan mode is in conflict with heating mode and the heating mode is the basic mode. No matter which indoor unit operates first, the unit will run in heating mode.

### 2.2 Overload protection function

When the tube temperature is a little low, the compressor raises the operation frequency; when the tube temperature is a little high, the compressor frequency is restricted or lows down the operation frequency; when the tube temperature is too high, the compressor protection stops running.

If the discharge temperature protection continuously appears for 6 times, the compressor can't resume running. The compressor can resume running after cutting off the power and then putting through the power. (if the running time of the compressor is longer than 7min, the protection times record will be cleared)

### 2.3 Discharge Protection Function

When the discharge temperature is a little low, the compressor raises the operation frequency; when the discharge temperature is a little high, the compressor frequency is restricted or lows down the operation frequency; when the discharge temperature is too high, the compressor protection stops running.

If the discharge temperature protection continuously appears for 6 times, the compressor can't resume running. The compressor can resume running after cutting off the power and then putting through the power. (if the running time of the compressor is longer than 7min, the protection times record will be cleared)

## 2.4 Communication malfunction

Detection of the quantity of installed indoor units:

After 3min of energizing, if the outdoor unit does not receive the communication data of certain indoor unit, the outdoor unit will judge that indoor unit is not installed and will treat it as it is not installed. If the outdoor unit receives the communication data of that indoor unit later, the outdoor unit will treat that unit as it is installed.

## 2.5 Overcurrent Protection

a. Overcurrent protection of complete unit; b. phase wire current protection; c. compressor phase current protection

## 2.6 Compressor high-pressure protection

2.6.1 When the high-pressure switch is detected cut off for 3s continuously, the compressor will enter high-pressure protection as it stops when reaching set temperature. Meanwhile, the outdoor unit will send the signal of "high-pressure protection" to the indoor units;

2.6.2 After the appearance of high-pressure protection, when the high-pressure switch is detected closed for 6s continuously, the compressor can resume running only after cutting off the power and then putting through the power.

## 2.7 Compressor overload protection

If the compressor overload switch is detected having movement, the indoor unit will display the corresponding malfunction as it stops when the indoor temperature reaching set temperature. When the compressor stops for more than 3min and the compressor overload switch is reset, the unit will resume operation status automatically. If the protection appears for more than 6 times (if the running time of the compressor is longer than 30min, the protection times record will be cleared), the unit can not resume operation status automatically, but can resume running only after cutting off the power and then putting through the power.

## 2.8 Compressor Phase-lacking Protection

When the compressor starts, if one of the three phases is detected open, the compressor will enter phase-lacking protection. The malfunction will be cleared after 1min, the unit will restart and then detect if there is still has phase-lacking protection. If the phase-lacking protection is detected for 6 times continuously, the compressor will not restart but can resume running only after cutting off the power and then putting through the power. If the running time of the compressor is longer than 7min, the protection times record will be cleared.

## 2.9 IPM Protection

2.9.1 When the IMP module protection is detected, the unit will stop as the indoor temperature reaching set temperature, PFC is closed, display IMP protection malfunction. After the compressor stops for 3min, the unit will resume operation status automatically; if the IMP protection is detected for more than 6 times continuously (If the running time of the compressor is longer than 7min, the protection times record will be cleared), the system will stop and send the signal of module protection to indoor unit. The unit can not resume operation status automatically, but can resume running only after cutting off the power and then putting through the power.

2.9.2 IMP module overheating protection

2.9.2.1 When  $T_{IMP} > 85^{\circ}\text{C}$ , prohibit to raise frequency;

2.9.2.2 When  $T_{IMP} \geq 90^{\circ}\text{C}$ , the operation frequency of compressor lows down by 15% every 90s according to the present capacity requirement of the complete unit. It will keep 90s after lowing down the frequency. After lowing down the frequency, if  $T_{IMP} \geq 90^{\circ}\text{C}$ , the unit will circulate the above movement until reaching the minimum frequency; if  $85^{\circ}\text{C} < T_{IMP} < 90^{\circ}\text{C}$ , the unit will run at this frequency; when  $T_{IMP} \leq 85^{\circ}\text{C}$ , the unit will run at the frequency according to the capacity requirement;

2.9.2.3 When  $T_{IMP} \geq 95^{\circ}\text{C}$ , the compressor stops. After the compressor stops for 3min, if  $T_{IMP} < 85^{\circ}\text{C}$ , the compressor and the outdoor fan will resume operation.



# Part II : Installation and Maintenance

## 7. Notes for Installation and Maintenance

### Safety Precautions: Important!

Please read the safety precautions carefully before installation and maintenance.

The following contents are very important for installation and maintenance.

Please follow the instructions below.

- The installation or maintenance must accord with the instructions.
- Comply with all national electrical codes and local electrical codes.
- Pay attention to the warnings and cautions in this manual.
- All installation and maintenance shall be performed by distributor or qualified person.
- All electric work must be performed by a licensed technician according to local regulations and the instructions given in this manual.
- Be caution during installation and maintenance. Prohibit incorrect operation to prevent electric shock, casualty and other accidents.



### Warnings

#### Electrical Safety Precautions:

1. Cut off the power supply of air conditioner before checking and maintenance.
2. The air condition must apply specialized circuit and prohibit share the same circuit with other appliances.
3. The air conditioner should be installed in suitable location and ensure the power plug is touchable.
4. Make sure each wiring terminal is connected firmly during installation and maintenance.
5. Have the unit adequately grounded. The grounding wire cant be used for other purposes.
6. Must apply protective accessories such as protective boards, cable-cross loop and wire clip.
7. The live wire, neutral wire and grounding wire of power supply must be corresponding to the live wire, neutral wire and grounding wire of the air conditioner.
8. The power cord and power connection wires cant be pressed by hard objects.
9. If power cord or connection wire is broken, it must be replaced by a qualified person.

10. If the power cord or connection wire is not long enough, please get the specialized power cord or connection wire from the manufacture or distributor. Prohibit prolong the wire by yourself.

11. For the air conditioner without plug, an air switch must be installed in the circuit. The air switch should be all-pole parting and the contact parting distance should be more than 1/8 inch.

12. Make sure all wires and pipes are connected properly and the valves are opened before energizing.

13. Check if there is electric leakage on the unit body. If yes, please eliminate the electric leakage.

14. Replace the fuse with a new one of the same specification if it is burnt down; dont replace it with a cooper wire or conducting wire.

15. If the unit is to be installed in a humid place, the circuit breaker must be installed.

#### Installation Safety Precautions:

1. Select the installation location according to the requirement of this manual.(See the requirements in installation part)
2. Handle unit transportation with care; the unit should not be carried by only one person if it is more than 44.09lb.
3. When installing the indoor unit and outdoor unit, a sufficient fixing bolt must be installed; make sure the installation support is firm.
4. Ware safety belt if the height of working is above 78 3/4 inch.
5. Use equipped components or appointed components during installation.
6. Make sure no foreign objects are left in the unit after finishing installation.

#### Refrigerant Safety Precautions:

1. Avoid contact between refrigerant and fire as it generates poisonous gas; Prohibit prolong the connection pipe by welding.
2. Apply specified refrigerant only. Never have it mixed with any other refrigerant. Never have air remain in the refrigerant line as it may lead to rupture or other hazards.
3. Make sure no refrigerant gas is leaking out when installation is completed.
4. If there is refrigerant leakage, please take sufficient measure to minimize the density of refrigerant.
5. Never touch the refrigerant piping or compressor without wearing glove to avoid scald or frostbite.


Improper installation may lead to fire hazard, explosion, electric shock or injury.

## Main Tools for Installation and Maintenance

<p>1. Level meter, measuring tape</p> 	<p>2. Screw driver</p> 	<p>3. Impact drill, drill head, electric drill</p> 
<p>4. Electroprobe</p> 	<p>5. Universal meter</p> 	<p>6. Torque wrench, open-end wrench, inner hexagon spanner</p> 
<p>7. Electronic leakage detector</p> 	<p>8. Vacuum pump</p> 	<p>9. Pressure meter</p> 
<p>10. Pipe pliers, pipe cutter</p> 	<p>11. Pipe expander, pipe bender</p> 	<p>12. Soldering appliance, refrigerant container</p> 

# 8. Installation Manual

## Installation procedures



Note: this flow is only for reference; please find the more detailed installation steps in this section.

## 8.1 Electrical Connections

1. Remove the handle at the right side plate of the outdoor unit (one screw).
2. Remove the cable clamp, connect the power connection cable with the terminal at the row of connection and fix the connection. The fitting line distributing must be consistent with the indoor unit. terminal of line bank. Wiring should meet that of indoor unit.
3. Fix power connection wire by wire clamp.
4. Ensure wire has been fixed well.
5. Install the handle.

**!** Including an air switch with suitable capacity, please note the following table. Air switch should be included magnet buckle and heating buckle function, it can protect the circuit-short and overload. (Caution: please do not use the fuse only for protect the circuit)

**!** An all-pole disconnection switch having a contact separation of at least 3mm in all pole should be connected in fixed wiring.


**!** Wrong wire connection may cause malfunction of some electric components. After fixing cable, ensure that leads between connection to fixed point have some space.

**!** The connection pipes and the connecting wirings of the unit A and unit B must be corresponding to each other respective.


**!** The appliance shall be installed in accordance with national wiring regulations.

Note: the above figures are only intended to be a simple diagram of the appliance and may not correspond to the appearance of the units that have been purchased.

### GWHD(18)ND3EO GWHD(18)ND3FO TM18H4O



### GWHD(24)ND3EO GWHD(24)ND3FO TM24H4O



## 8.2 Installing the Outdoor Unit

### Location

Use bolts to secure the unit to a flat, solid floor.

When mounting the unit on a wall or the roof, make sure the support is firmly secured so that it cannot move in the event of intense vibrations or a strong wind.

Do not install the outdoor unit in pits or air vents

### Installing the pipes

Use suitable connecting pipes and equipment for the refrigerant R410A.

Models(ft)	18K	24K
Max. connection pipe length(ft)	65.6	196.8
Max. connection pipe length(Simpleone indoor unit)(ft)	32.8	65.6

The refrigerant pipes must not exceed the maximum heights 16.4ft(18K) or 32.8ft(24K).

Wrap all the refrigerant pipes and joints.

Tighten the connections using two wrenches working in opposite directions.


**Caution: Installation Must be Performed in Accordance with the NEC/CEC by Authorized Personnel Only.**

Humid air left inside the refrigerant circuit can cause compressor malfunction. After having connected the indoor and outdoor units, bleed the air and humidity from the refrigerant circuit using a vacuum pump.

- (1) Unscrew and remove the caps from the 2-way and 3-way valves.
- (2) Unscrew and remove the cap from the service valve.
- (3) Connect the vacuum pump hose to the service valve.
- (4) Operate the vacuum pump for 10-15 minutes until an absolute vacuum of 10 mm Hg has been reached.
- (5) With the vacuum pump still in operation, close the low-pressure knob on the vacuum pump coupling. Stop the vacuum pump.
- (6) Open the 2-way valve by 1/4 turn and then close it after 10 seconds. Check all the joints for leaks using liquid soap or an electronic leak device.
- (7) Turn the body of the 2-way and 3-way valves. Disconnect the vacuum pump hose.
- (8) Replace and tighten all the caps on the valves.

Hex nut diameter(inch)	Tightening torque(ft·lbf)
Φ1/4	11.10~4.75
Φ3/8	20.12~29.50
Φ1/2	33.19~40.56
Φ5/8	44.24~47.94
Φ3/4	51.32~55.31




18K unit need to be installed the indoor unit



### Install the drain fitting and the drain hose(for model with heat pump only)

Condensation is produced and flows from the outdoor unit when the appliance is operating in the heating mode. In order not to disturb neighbours and to respect the environment, install a drain fitting and a drain hose to channel the condensate

water. Install the drain fitting and rubber washer on the outdoor unit chassis and connect a drain hose to it as shown in the figure.





## 8.3 Installation Dimension Diagram

⚠ Use suitable instruments for the refrigerant R410A.

- Do not use any other refrigerant than R410A.


⚠ Do not use mineral oils to clean the unit.

⚠ The installation must be done by trained and qualified service personnel with reliability according to this manual.


⚠ Contact service center before installation to avoid the malfunction due to unprofessional installation.

⚠ When picking up and moving the units, you must be guided by trained and qualified person.


⚠ Ensure that the recommended space is left around the appliance .



### GWHD(18)ND3EO GWHD(18)ND3FO



### GWHD(24)ND3EO GWHD(24)ND3FO



## 8.4 Check after Installation

Check Items	Problems Owing to Improper Installation
Is the installation reliable?	The unit may drop, vibrate or make noises
Has the gas leakage been checked?	May cause unsatisfactory cooling (heating) effect
Is the thermal insulation of the unit sufficient?	May cause condensation and water dropping
Is the drainage smooth?	May cause condensation and water dropping
Does the power supply voltage accord with the rated voltage specified on the nameplate?	The unit may bread down or the components may be burned out
Are the lines and pipelines correctly installed?	The unit may bread down or the components may be burned out
Has the unit been safely grounded?	Risk of electrical leakage
Are the models of lines in conformity with requirements?	The unit may bread down or the components may be burned out
Are there any obstacles near the air inlet and outlet of the indoor and outdoor units?	The unit may bread down or the components may be burned out
Have the length of refrigerating pipe and refrigerant charge amount been recorded?	It is not easy to decide the charge amount of refrigerant.

## 9. Troubleshooting

### 9.1 Flashing LED of Indoor/Outdoor Unit and Primary Judgement

#### 1. Requirement of malfunction display

When several malfunctions happen at the same time, malfunction codes will be displayed circularly.

#### 2. Malfunction display method

(1) Hardware malfunction: it will be displayed immediately, please refer to "Malfunction status sheet";

(2) Operation status: it will be displayed immediately, please refer to "Malfunction status sheet";

(3) Other malfunction: It will be displayed after the compressor has been stopped for 200s, please refer to "Malfunction status sheet".

(Note: when the compressor starts up again, malfunction display waiting time (200s) will be cleared.)

#### 3. Malfunction display control

Indoor unit displays malfunction code as shown in the sheet below. ODU communication light will be off for 1s and then blink for 1s circularly.

#### 4. Viewing malfunction code through remote controller

Enter viewing malfunction code: pressing light button for 6 times within 3S to view malfunction code;

Exit viewing malfunction code: pressing light button for 6 times within 3S or after the malfunction code is displayed for 5min.

Malfunction status sheet		
Malfunction name	Malfunction type	Nixie tube
Zero cross detection circuit malfunction(for indoor unit)	Hardware malfunction	U8
Malfunction protection of jumper cap(for indoor unit)	Hardware malfunction	C5
Feedback of without IDU motor(for indoor unit)	Hardware malfunction	H6
Indoor ambient temperature sensor is open/short circuited	Hardware malfunction	F1
Indoor evaporator temperature sensor is open/short circuited	Hardware malfunction	F2
Liquid valve temperature sensor is open/short circuited	Hardware malfunction	b5
Gas valve temperature sensor is open/short circuited	Hardware malfunction	b7
Modular temperature sensor is open/short circuited	Hardware malfunction	P7
Outdoor ambient temperature sensor is open/short circuited	Hardware malfunction	F3
Outdoor condenser middle pipe temperature sensor is open/short circuited	Hardware malfunction	F4
Outdoor discharge temperature sensor is open/short circuited	Hardware malfunction	F5
Communication malfunction	Hardware malfunction	E6
Malfunction of phase current detection circuit for compressor	Hardware malfunction	U1
Module high temperature protection	Viewing malfunction code through remote controller within 200s; displayed directly on nixietube after 200s	P8
Refrigerant lacking or blockage protection of system (not available for residential ODU)		F0
Charging malfunction of capacitor	Hardware malfunction	PU
High pressure protection of system	Hardware malfunction	E1
Low pressure protection of system (reserved)	Hardware malfunction	E3




Compressor overload protection	Viewing malfunction code through remote controller within 200s; displayed directly on nixietube after 200s	H3
Indoor unit and outdoor unit do not match	Hardware malfunction	LP
Malfunction of memory chip	Hardware malfunction	EE
Wrong connection of communication wire or malfunction of electronic expansion valve	Hardware malfunction	dn
Malfunction protection of outdoor fan 1	Hardware malfunction	L3
Detection status of wrong connection of communication wire or malfunction of electronic expansion valve	Operation status	dd
Mode conflict	Operation status	E7
Refrigerant recycling mode	Operation status	Fo
X-fan	Operation status	AL
Defrosting or oil return in heating mode	Operation status	H1
Start failure of compressor	Viewing malfunction code through remote controller within 200s; displayed directly on nixietube after 200s	Lc
High discharge temperature protection of compressor		E4
Overload protection		E8
Whole unit overcurrent protection		E5
Compressor phase current protection		P5
Compressor desynchronizing		H7
Compressor phase-lacking/phase-inverse protection		Ld
IPM modular protection		H5
DC bus-bar low voltage protection		PL
DC bus-bar high voltage protection		PH
PFC protection		HC
The four-way valve is abnormal		U7


## 9.2 Malfunction Checking and Elimination

Note: discharge the position in below pictures with discharge resistance after open the top cover and check if the voltage is below 20V with universal meter, then begin to check.

18K:



24K:



1 IPM protection malfunction:


Main checking point:

- If the input voltage of the unit is within normal range?
- If the connection wire of compressor is connected well? Is it loose? If the connection sequence is correct?
- If the resistance of compressor coil is normal? If the isolation of compressor coil with copper pipe is good?
- If the unit is overloaded? If the heat radiation of the unit is good?
- If the refrigerant charge is suitable?

Flow chart:

- If the resistance of compressor coil is normal? If the isolation of compressor coil with copper pipe is good?
- If the unit is overloaded? If the heat radiation of the unit is good?
- If the refrigerant charge is suitable?

Flow chart:




2. PFC protection malfunction, capacity charging malfunction

Main checking points:


- If the wiring of the induction is connected well and if the induction is broken;
- If the mainboard is broken;

Flow chart:

For 18K



For 24K





### 3. Compressor desynchronizing malfunction

Main checking points:

- If the pressure of the system is too high;
- If the electric expansion valve is working normally or it is broken;
- If the radiation of the unit is good;

Flow chart:






#### 4. Compressor overload, diacharge protectionmalfunction

Main checking points:

- If the eletric expansion valve is connected well or it is broken;
- If there is refrigerant leakage;
- If the overload protector is broken;

Flow chart:




Note: the detection method of the coil of the eletric expansion valve: there is five pieces of coil of the eletric expansion valve, the resistance of one of them (the leftmost or the rightmost one) is almost the same as the resistance of other terminal (within 100  $\Omega$  ). Judge the condition of the electronic expansion valve through detecting these resistance.

## 5. Start failuremalfunction

Main checking points:

- If the connection wire of the compressor is connected properly;
- If the stop duration of the compressor is sufficient;
- If the compressor is broken;
- If the refrigerant charging amount is too much;

Flow chart:






6. Temperature sensor malfunction

Main checking points:

- If the temperature sensor is damaged or broken
- If the terminal of the temperature sensor is loosened or not connected;
- If the mainboard is broken;

Flow chart:




## 7. DC fan malfunction

Main checking points:

- If the outdoor fan is blocked by foreign objects;
- The connection wire of DC fan is connected reliably? If it is loose?

Flow chart:





## 8. Communication malfunction

Main checking points:

- If the connection wire between the indoor unit and outdoor unit is connected well, if the wires inside the unit is connected well;
- If the indoor mainboard or outdoor main board is broken;

Flow chart:






9. Anti-high temperatureand overload malfunction

Main checking points:

- If the outdoor ambient temperature is within the normal range;
- If the indoor fan and outdoor fan are running normally;
- If the indoor and outdoor radiation environment is good;

Flow chart:



## 9.3 Maintenance Method for Normal Malfunction

### 1. Air Conditioner Cant be Started Up

Possible Causes	Discriminating Method (Air conditioner Status)	Troubleshooting
No power supply, or poor connection for power plug	After energization, operation indicator isnt bright and the buzzer cant give out sound	Confirm whether its due to power failure. If yes, wait for power recovery. If not, check power supply circuit and make sure the power plug is connected well.
Wrong wire connection between indoor unit and outdoor unit, or poor connection for wiring terminals	Under normal power supply circumstances, operation indicator isnt bright after energization	Check the circuit according to circuit diagram and connect wires correctly. Make sure all wiring terminals are connected firmly
Electric leakage for air conditioner	After energization, room circuit breaker trips off at once	Make sure the air conditioner is grounded reliably Make sure wires of air conditioner is connected correctly Check the wiring inside air conditioner. Check whether the insulation layer of power cord is damaged; if yes, place the power cord.
Model selection for air switch is improper	After energization, air switch trips off	Select proper air switch
Malfunction of remote controller	After energization, operation indicator is bright, while no display on remote controller or buttons have no action.	Replace batteries for remote controller Repair or replace remote controller

### 2. Poor Cooling (Heating) for Air Conditioner

Possible Causes	Discriminating Method (Air conditioner Status)	Troubleshooting
Set temperature is improper	Observe the set temperature on remote controller	Adjust the set temperature
Rotation speed of the IDU fan motor is set too low	Small wind blow	Set the fan speed at high or medium
Filter of indoor unit is blocked	Check the filter to see its blocked	Clean the filter
Installation position for indoor unit and outdoor unit is improper	Check whether the installation position is proper according to installation requirement for air conditioner	Adjust the installation position, and install the rainproof and sunproof for outdoor unit
Refrigerant is leaking	Discharged air temperature during cooling is higher than normal discharged wind temperature; Discharged air temperature during heating is lower than normal discharged wind temperature; Units pressure is much lower than regulated range	Find out the leakage causes and deal with it. Add refrigerant.
Malfunction of 4-way valve	Blow cold wind during heating	Replace the 4-way valve
Malfunction of capillary	Discharged air temperature during cooling is higher than normal discharged wind temperature; Discharged air temperature during heating is lower than normal discharged wind temperature; Unit pressure is much lower than regulated range. If refrigerant isnt leaking, part of capillary is blocked	Replace the capillary
Flow volume of valve is insufficient	The pressure of valves is much lower than that stated in the specification	Open the valve completely
Malfunction of horizontal louver	Horizontal louver cant swing	Refer to point 3 of maintenance method for details
Malfunction of the IDU fan motor	The IDU fan motor cant operate	Refer to troubleshooting for H6 for maintenance method in details
Malfunction of the ODU fan motor	The ODU fan motor cant operate	Refer to point 4 of maintenance method for details
Malfunction of compressor	Compressor cant operate	Refer to point 5 of maintenance method for details

### 3. Horizontal Louver Cant Swing

Possible Causes	Discriminating Method (Air conditioner Status)	Troubleshooting
Wrong wire connection, or poor connection	Check the wiring status according to circuit diagram	Connect wires according to wiring diagram to make sure all wiring terminals are connected firmly
Stepping motor is damaged	Stepping motor cant operate	Repair or replace stepping motor
Main board is damaged	Others are all normal, while horizontal louver cant operate	Replace the main board with the same model

#### 4. ODU Fan Motor Cant Operate

Possible causes	Discriminating method (air conditioner status)	Troubleshooting
Wrong wire connection, or poor connection	Check the wiring status according to circuit diagram	Connect wires according to wiring diagram to make sure all wiring terminals are connected firmly
Capacity of the ODU fan motor is damaged	Measure the capacity of fan capacitor with an universal meter and find that the capacity is out of the deviation range indicated on the nameplate of fan capacitor.	Replace the capacity of fan
Power voltage is a little low or high	Use universal meter to measure the power supply voltage. The voltage is a little high or low	Suggest to equip with voltage regulator
Motor of outdoor unit is damaged	When unit is on, cooling/heating performance is bad and ODU compressor generates a lot of noise and heat.	Change compressor oil and refrigerant. If no better, replace the compressor with a new one

#### 5. Compressor Cant Operate

Possible causes	Discriminating method (air conditioner status)	Troubleshooting
Wrong wire connection, or poor connection	Check the wiring status according to circuit diagram	Connect wires according to wiring diagram to make sure all wiring terminals are connected firmly
Capacity of compressor is damaged	Measure the capacity of fan capacitor with an universal meter and find that the capacity is out of the deviation range indicated on the nameplate of fan capacitor.	Replace the compressor capacitor
Power voltage is a little low or high	Use universal meter to measure the power supply voltage. The voltage is a little high or low	Suggest to equip with voltage regulator
Coil of compressor is burnt out	Use universal meter to measure the resistance between compressor terminals and its 0	Repair or replace compressor
Cylinder of compressor is blocked	Compressor cant operate	Repair or replace compressor

#### 6. Air Conditioner is Leaking


Possible causes	Discriminating method (air conditioner status)	Troubleshooting
Drain pipe is blocked	Water leaking from indoor unit	Eliminate the foreign objects inside the drain pipe
Drain pipe is broken	Water leaking from drain pipe	Replace drain pipe
Wrapping is not tight	Water leaking from the pipe connection place of indoor unit	Wrap it again and bundle it tightly

#### 7. Abnormal Sound and Vibration

Possible causes	Discriminating method (air conditioner status)	Troubleshooting
When turn on or turn off the unit, the panel and other parts will expand and theres abnormal sound	Theres the sound of "PAPA"	Normal phenomenon. Abnormal sound will disappear after a few minutes.
When turn on or turn off the unit, theres abnormal sound due to flow of refrigerant inside air conditioner	Water-running sound can be heard	Normal phenomenon. Abnormal sound will disappear after a few minutes.
Foreign objects inside the indoor unit or therere parts touching together inside the indoor unit	Theres abnormal sound fro indoor unit	Remove foreign objects. Adjust all parts position of indoor unit, tighten screws and stick damping plaster between connected parts
Foreign objects inside the outdoor unit or therere parts touching together inside the outdoor unit	Theres abnormal sound fro outdoor unit	Remove foreign objects. Adjust all parts position of outdoor unit, tighten screws and stick damping plaster between connected parts
Short circuit inside the magnetic coil	During heating, the way valve has abnormal electromagnetic sound	Replace magnetic coil
Abnormal shake of compressor	Outdoor unit gives out abnormal sound	Adjust the support foot mat of compressor, tighten the bolts
Abnormal sound inside the compressor	Abnormal sound inside the compressor	If add too much refrigerant during maintenance, please reduce refrigerant properly. Replace compressor for other circumstances.

## 10. Exploded View and Parts List

GWHD(18)ND3EO GWHD(18)ND3FO TM18H4O



The component picture is only for reference; please refer to the actual product.




NO.	Description	Part Code		Qty
		GWHD(18)ND3EO	GWHD(18)ND3FO	
	Product Code	CB228W04100	CB228W07600	
1	Front Grill	01473050	01473049	1
2	Front Panel Assy	01433069	01433069	1
3	Chassis Sub-assy	02803280P	02803263P	1
4	Drainage Connector	/	06123401	1
5	Drainage hole Cap	/	06813401	1
6	Gas-liquid Separator Assy	07223048	07223048	1
7	Compressor and Fittings	0010524501G	00105249G	1
8	Electric Heater(Compressor)	7651873215	7651300403	1
9	Tube Connector Sub-assy	06643008	/	1
10	Magnet Coil	4300040045	4300040045	1
11	4-Way Valve Assy	03015200001	03073328	1
12	Right Side Plate	0131410000901P	0130326801P	1
13	Valve Support Assy	0713395401	03016300003	1
14	Electronic Expansion Valve assy	0713395301	0171312802	1
15	Valve Support Sub-Assy	07133845	0171312802P	1
16	Cut off Valve	071302391	071302391	1
17	Cut off Valve	07130239	071302391	1
18	Valve Cover	/	/	/
19	Electric Expand Valve Fitting	43000084	43000084	1
20	Electric Expand Valve Fitting	4300008401	4300008401	1
21	Temperature Sensor	39000073	39000073	1
22	Temperature Sensor	3900007301	3900007301	1
23	Wiring Clamp	26115004	26115004	1
24	Temperature Sensor	39000073	39000073	1
25	Rear Grill	01574100003	01473043	1
26	Condenser Assy	0116398001	01163938	1
27	Clapboard Assy	0123315301	0123315301	1
28	Coping	01255006P	01255005P	1
29	Supporting Board(Condenser)	01795010	01795010	1
30	Motor Support Sub-Assy	01705025	01705036	1
31	Fan Motor	1501403402	1501506402	1
32	Left Side Plate	01305043P	01305093P	1
33	Axial Flow Fan	10335014	10335008	1
34	Left Handle	26235401	2623305301	1
35	Connecting Cable	/	/	/
36	Electric Box Assy	10000100020	10000100023	1
37	Electric Box	20113015	20113027	1
38	Radiator	/	49010252	1
39	Main Board	30138000311	30138000310	1

Above data is subject to change without notice.

NO.	Description	Part Code	Qty
		TM18H4O	
		Product Code	
		CB228W07700	
1	Front Grill	01473049	1
2	Front Panel Assy	00000300024	1
3	Chassis Sub-assy	02803263P	1
4	Drainage Connector	06123401	1
5	Drainage hole Cap	06813401/76713033/76713068	1
6	Gas-liquid Separator Assy	07223048	1
7	Compressor and Fittings	00105249G	1
8	Electric Heater(Compressor)	7651300403	1
9	Tube Connector Sub-assy	/	/
10	Magnet Coil	4300040045	1
11	4-Way Valve Assy	03073328	1
12	Right Side Plate	0130326801P	1
13	Valve Support Assy	03016300003	1
14	Electronic Expansion Valve assy	03017400020	1
15	Valve Support Sub-Assy	0171312802P	1
16	Cut off Valve	07130239	1
17	Cut off Valve	071302391	1
18	Valve Cover	/	/
19	Electric Expand Valve Fitting	43000084	1
20	Electric Expand Valve Fitting	4300008401	1
21	Temperature Sensor	39000073	1
22	Temperature Sensor	3900007301	1
23	Wiring Clamp	26115004	1
24	Temperature Sensor	39000073	1
25	Rear Grill	01473043	1
26	Condenser Assy	011002000279	1
27	Clapboard Assy	0123315301	1
28	Coping	012049000007P	1
29	Supporting Board(Condenser)	01795010	1
30	Motor Support Sub-Assy	01705067	1
31	Fan Motor	1501506402	1
32	Left Side Plate	01305093P	1
33	Axial Flow Fan	10335008	1
34	Left Handle	2623305301	1
35	Connecting Cable	/	/
36	Electric Box Assy	10000100023	1
37	Electric Box	20113027	1
38	Radiator	49010252	1
39	Main Board	30138000310	1

Above data is subject to change without notice.



The component picture is only for reference; please refer to the actual product.

NO.	Description	Part Code		Qty
		GWHD(24)ND3EO		
	Product code	CB228W04200	CB228W04203	
1	Front Grill	01473050	01473050	1
2	Cabinet	0143500401P	0143500401P	1
3	Left Handle	26235401	26235401	1
4	Front Side Plate	01305086P	01305086P	1
5	Electrical Heater (Chassis)	7651000411	7651000411	1
6	Chassis Sub-assy	02803280P	02803280P	1
7	Gas-liquid Separator	07223048	07223048	1
8	Compressor and Fittings	0010524501G	0010524501	3
9	Electric Heater(Compressor)	7651873215	7651873215	1
10	Tube Connector Sub-assy	03003900001	06643008	1
11	4-Way Valve Assy	03015200001	03015200001	1
12	Connection Pipe	03509700042	03509700042	1
13	Magnet Coil	4300040045	4300040045	1
14	Electronic Expansion Valve assy	0713395301	0713395301	1
15	Valve Support Assy	0713395401	0713395401	1
16	Cut off Valve	071302391	071302391	1
17	Cut off Valve	07130239	07130239	1
18	Right Side Plate	0131410000901P	0131410000901P	1
19	Wiring Cover Sub-assy	01264100034	01264100034	1
20	Handle Assy	02204100008	02204100008	1
21	Electric Expand Valve Fitting	4300008402	4300008402	1
22	Electric Expand Valve Fitting	4300008401	4300008401	1
23	Electric Expand Valve Fitting	43000084	43000084	1
24	Temperature Sensor	3900030901	3900030901	1
25	Temperature Sensor	3900007306	3900007306	1
26	Temperature Sensor	3900007305	3900007305	1
27	Wiring Clamp	26115004	26115004	1
28	Temperature Sensor	39000073	39000073	1
29	Rear Grill	01574100003	01574100003	1
30	Condenser Assy	0116398001	0116398001	1
31	Electric Box (Fireproofing)	01413426	01413426	1
32	Clapboard Sub-Assy	01233190	01233190	1
33	Motor Support Sub-Assy	01705025	01705025	1
34	Top Cover Sub-Assy	01255007	01255007	1
35	Fan Motor	1501403402	1501403402	1
36	Condenser Support Plate	01175092	01175092	1
37	Axial Flow Fan	10335014	10335014	1
38	Left Side Plate	01305043P	01305043P	1
39	Connecting Cable	4002054026	/	1
40	Electric Box Assy	10000100020	10000100020	1
41	Terminal Board	42010178	42010178	1
42	Connection Support	01703211	01703211	1
43	Electric Box	20113015	20113015	1
44	Main Board	30138000311	30138000311	1
45	Electric Box Cover Sub-Assy	02603217	02603217	1

Above data is subject to change without notice.

NO.	Description	Part Code		Qty
		GWHD(24)ND3FO	TM24H4O	
	Product code	CB228W07500	CB228W07800	
1	Front Grill	01473050	01473050	1
2	Cabinet	0143500401P	0143500401P	1
3	Left Handle	26235401	02113031	1
4	Front Side Plate	01305086P	01305086P	1
5	Electrical Heater (Chassis)	7651000411	7651000411	1
6	Chassis Sub-assy	02803280P	02803280P	1
7	Gas-liquid Separator	07223048	07223048	1
8	Compressor and Fittings	0010524501	0010524501	3
9	Electric Heater(Compressor)	7651873215	7651873215	1
10	Tube Connector Sub-assy	06643008	06643008	1
11	4-Way Valve Assy	03015200001	03015200001	1
12	Connection Pipe	03509700042	03509700042	1
13	Magnet Coil	4300040045	4300040045	1
14	Electronic Expansion Valve assy	0713395301	0713395301	1
15	Valve Support Assy	0713395401	0713395401	1
16	Cut off Valve	071302391	07130239	1
17	Cut off Valve	07130239	07130239	1
18	Right Side Plate	0131410000901P	0131410000901P	1
19	Wiring Cover Sub-assy	01264100034	01264100034	1
20	Handle Assy	02204100008	02204100008	1
21	Electric Expand Valve Fitting	4300008402	43000084	1
22	Electric Expand Valve Fitting	4300008401	4300008401	1
23	Electric Expand Valve Fitting	43000084	4300008402	1
24	Temperature Sensor	3900030901	3900030901	1
25	Temperature Sensor	39000073	39000073	1
26	Temperature Sensor	3900007305/3900007306	3900007305/3900007306	1
27	Wiring Clamp	26115004	26115004	1
28	Temperature Sensor	39000073	3900030901	1
29	Rear Grill	01574100003	01574100003	1
30	Condenser Assy	0116398001	0116398001	1
31	Electric Box (Fireproofing)	01413426	01413426	1
32	Clapboard Sub-Assy	01233190	01233190	1
33	Motor Support Sub-Assy	01705025	017012000017	1
34	Top Cover Sub-Assy	01255007	01255007	1
35	Fan Motor	1501403402	017012000017	1
36	Condenser Support Plate	01175092	01175092	1
37	Axial Flow Fan	10335014	10335014	1
38	Left Side Plate	01305043P	01305043P	1
39	Connecting Cable	/	/	/
40	Electric Box Assy	10000100020	10000100020	1
41	Terminal Board	42010178	42010178	1
42	Connection Support	01703211	01703211	1
43	Electric Box	20113015	20113015	1
44	Main Board	30138000311	30138000311	1
45	Electric Box Cover Sub-Assy	02603217	02603217	1

Above data is subject to change without notice.



Warning: Be sure to wait for a minimum of 20 minutes after turning off all power supplies and discharge the refrigerant completely before removal.


**WHD(18)ND3EO GWHD(18)ND3FO TM18H4O**

1.Remove big handle and wire connection cover


Before disassembly

Remove the screws fixing big handle and right side plate to remove the big handle.




Remove the screws fixing wire connection cover and right side plate to remove the wire connection cover.






big handle






wire connection cover




Steps	Procedure
2.Remove top cover	<div>Remove the screws fixing top cover, panel and left &amp; right side plate, to remove top cover.</div> 
3.Remove grille	<div>Remove the screws fixing grille and panel, to remove the grille on the panel.</div> 
4.Remove panel	<div>Remove the screws fixing panel, chassis and motor support, to remove the panel.</div> 









Steps	Procedure
<p>5.Remove right side plate</p> <p>Remove the screws fixing right side plate, valve support and guard grille, to remove the right side plate.</p>	 <p>right side plate</p>
<p>6.Remove guard grille</p> <p>Remove the screws fixing guard grille and left side plate to remove guard grille.</p>	 <p>guard grille</p>
<p>7.Remove left side plate</p> <p>Remove the screws fixing chassis and condenser support, to remove the left side plate.</p>	 <p>left side plate</p>





Steps	Procedure
8.Remove condenser support	 <p>condenser support</p>
9.Remove axial fan blade	 <p>axial fan blade</p>
10.Remove motor and motor support sub-assy	 <p>motor</p> <p>motor support sub-assy</p>




Steps	Procedure
<p>11.Remove electric box sub-assy</p> <p>Remove the tapping screws fixing isolation sheet, loosen the wire binds, pull out the terminal, lift to remove the electric box sub-assy.</p>	 <p>electric box sub-assy</p>
<p>12.Remove PFC electrical inductance</p> <p>Remove the screws fixing PFC electrical inductance and isolation sheet, to remove the PFC electrical inductance.</p>	 <p>PFC electrical inductance</p>
<p>13.Remove four-way valve sub-assy</p> <p>Welding cut the welding point jointing the four-way valve with blowtorch to remove the four-way valve sub-assy. (Note: please make sure theres no refrigerant in the unit before remove any tube or compressor)</p>	 <p>four-way valve sub-assy</p>

Steps	Procedure	
14.Remove suction pipe sub-assy	<p>Welding cut the welding point jointing the suction pipe sub-assy, compressor and liquid receiver, to remove the suction pipe sub-assy.</p>	 <p>suction pipe sub-assy</p>
15.Remove liquid receiver		
16.Remove the isolation sheet assy	<p>Remove the screws fixing isolation sheet and liquid receiver and lift to remove the liquid receiver.</p>	 <p>liquid receiver</p>
	<p>Remove the screws fixing isolation sheet and condenser side plate, to remove the isolation sheet assy.</p>	 <p>isolation sheet assy</p>




Steps	Procedure
<p>17.Remove compressor</p> <p>Remove the screw nuts fixing compressor foots and chassis with spanner, as well as the foot cushion, to remove the compressor.</p>	
<p>18.Remove valve support assy</p> <p>Remove the screws fixing valve support assy and chassis sub-assy, to remove the valve support assy.</p>	
<p>19.Remove EXV assy</p> <p>Welding cut the welding point jointing EXV sub-assy and refrigerant collection pipe, to remove the EXV assy. (Note: fully pack the big valve with wet cloth when welding cutting, to avoid high temperature damage of valve)</p>	





GWHD(24)ND3EO GWHD(24)ND3FO TM24H4O

Steps		Procedure	
1. Remove valve cover and top panel			
a	Twist off the screws used for fixing and valve cover , pull valve cover up ward to remove it.		
b	Remove the 3 screws connecting the top panel with the front panel and the right side plate, and then remove the top panel.		
2. Remove grille,front side plate and panel.			
a	Remove the 2 screws connecting the grille and the panel, and then remove the grille.		
b	Remove the 1 screw connecting the front side plate and the panel,and then remove the front side plate.		




Steps	Procedure	
c	Remove the 5 screws connecting the panel with the chassis and the motor support, and then remove the panel.	 <p>panel</p>
3. Remove right side plate and left side plate		
a	Remove the screws connecting the right side plate with the chassis, the valve support and the electric box, and then remove the right side plate assy.	 <p>right side plate</p>
b	Remove the screws connecting the left side plate and the chassis, and then remove the left side plate assy.	 <p>left side plate</p>




Steps	Procedure	
4. Remove fan motor and axial flow blade		
a	Remove the nuts fixing the blade and then remove the axial flow blade.	
b	Remove the 4 tapping screws fixing the motor; disconnect the leading wire insert of the motor and then remove the motor. Remove the 2 tapping screws fixing the motor support and then pull the motor support upwards to remove it.	
5. Remove electric box		
	Remove the screws fixing the electric box sub-assy; loosen the wire bundle; pull out the wiring terminals and then pull the electric box upwards to remove it.	

Steps	Procedure	
6.Remove soundproof sponge and 4-way valve assy		
a	Since the piping ports on the soundproof sponge are torn easily, remove the soundproof sponge carefully	
b	Discharge the refrigerant completely;unsolder the pipelines connecting the compressor and the condenser assy,and then remove the 4-way valve assy.	
		
7. Remove Isolation sheet		
	Remove the 3 screws fixing the isolation sheet and then remove the Isolation sheet.	



Steps	Procedure	
8. Remove Cut off Valve and Valve Support		
	<p>Remove the 2 bolts fixing the valve subassemblies. Unsolder the welding joint connecting the gas valve and the return air pipe. Remove the gas valve. (Note: When unsoldering the soldering joint, wrap the gas valve with wet cloth completely to avoid damage to the valve caused by high temperature.) Unsolder the welding joint connecting the liquid valve and the connecting pipe. Remove the liquid valve. Remove screws fixing valve support and then remove the valve support; remove the screw fixing the condenser and then pull the condenser upwards to remove it.</p>	
9. Remove compressor		
	<p>Remove the 3 foot nuts fixing the compressor and then remove the compressor.</p>	
10. Remove support		
a	<p>Remove the screws connecting the support and condenser assy, and then remove the support.</p>	

Steps		
11.Remove condenser sub-assy		
	<p data-bbox="196 471 683 537">Remove the chassis sub-assy and condenser sub-assy.</p>	

# Appendix:

## Appendix 1: Reference Sheet of Celsius and Fahrenheit

Conversion formula for Fahrenheit degree and Celsius degree:  $T_f = T_c \times 1.8 + 32$

Set temperature

Fahrenheit display temperature (°F)	Fahrenheit (°F)	Celsius (°C)	Fahrenheit display temperature (°F)	Fahrenheit (°F)	Celsius (°C)	Fahrenheit display temperature (°F)	Fahrenheit (°F)	Celsius (°C)
61	60.8	16	69/70	69.8	21	78/79	78.8	26
62/63	62.6	17	71/72	71.6	22	80/81	80.6	27
64/65	64.4	18	73/74	73.4	23	82/83	82.4	28
66/67	66.2	19	75/76	75.2	24	84/85	84.2	29
68	68	20	77	77	25	86	86	30

Ambient temperature

Fahrenheit display temperature (°F)	Fahrenheit (°F)	Celsius (°C)	Fahrenheit display temperature (°F)	Fahrenheit (°F)	Celsius (°C)	Fahrenheit display temperature (°F)	Fahrenheit (°F)	Celsius (°C)
32/33	32	0	55/56	55.4	13	79/80	78.8	26
34/35	33.8	1	57/58	57.2	14	81	80.6	27
36	35.6	2	59/60	59	15	82/83	82.4	28
37/38	37.4	3	61/62	60.8	16	84/85	84.2	29
39/40	39.2	4	63	62.6	17	86/87	86	30
41/42	41	5	64/65	64.4	18	88/89	87.8	31
43/44	42.8	6	66/67	66.2	19	90	89.6	32
45	44.6	7	68/69	68	20	91/92	91.4	33
46/47	46.4	8	70/71	69.8	21	93/94	93.2	34
48/49	48.2	9	72	71.6	22	95/96	95	35
50/51	50	10	73/74	73.4	23	97/98	96.8	36
52/53	51.8	11	75/76	75.2	24	99	98.6	37
54	53.6	12	77/78	77	25			

## Appendix 2: Configuration of Connection Pipe

1. Standard length of connection pipe

- 16.4ft, 24.6ft, 26.2ft.

2. Min. length of connection pipe is 9.84ft.

3. Max. length of connection pipe and max. high difference.

4. The additional refrigerant oil and refrigerant charging required after prolonging connection pipe

- After the length of connection pipe is prolonged for 32.8ft at the basis of standard length, you should add 5ml of refrigerant oil for each additional 16.4ft of connection pipe.
- The calculation method of additional refrigerant charging amount (on the basis of liquid pipe):
- Basing on the length of standard pipe, add refrigerant according to the requirement as shown in the table. The additional refrigerant charging amount per meter is different according to the diameter of liquid pipe. See the following sheet.
- Additional refrigerant charging amount = prolonged length of liquid pipe X additional refrigerant charging amount per meter

Additional refrigerant charging amount for R22, R407C, R410A and R134a			
Diameter of connection pipe		Outdoor unit throttle	
Liquid pipe(inch)	Gas pipe(inch)	Cooling only(oz/ft.)	Cooling and heating(oz/ft.)
Φ0.23	Φ0.37 or Φ0.47	0.53	0.71
Φ0.23 or Φ0.37	Φ0.63 or Φ0.75	0.53	0.71
Φ0.47	Φ0.75 or Φ0.84	1.06	4.23
Φ0.63	Φ1.0 or Φ1.25	2.12	4.23
Φ0.75	/	8.82	8.82
Φ0.84	/	12.34	12.34


## Appendix 3: Pipe Expanding Method

### ⚠ Note:

**Improper pipe expanding is the main cause of refrigerant leakage. Please expand the pipe according to the following steps:**

#### A: Cut the pip


- Confirm the pipe length according to the distance of indoor unit and outdoor unit.
- Cut the required pipe with pipe cutter.



#### B: Remove the burrs


- Remove the burrs with shaper and prevent the burrs from getting into the pipe.

#### C: Put on suitable insulating pipe



#### D: Put on the union nut

- Remove the union nut on the indoor connection pipe and outdoor valve; install the union nut on the pipe.




#### E: Expand the port

- Expand the port with expander.

### ⚠ Note:


- "A" is different according to the diameter, please refer to the sheet below:

Outer diameter(inch)	A(inch)	
	Max	Min
Φ1/4	2/39	1/36
Φ3/8	1/16	1/51
Φ1/2	1/14	1/51
Φ5/8	5/53	2/23



#### F: Inspection

- Check the quality of expanding port. If there is any blemish, expand the port again according to the steps above.



# Appendix 4: List of Resistance for Temperature Sensor

Resistance Table of Ambient Temperature Sensor for Indoor and Outdoor (15K)

Temp.(°F)	Resistance(kΩ)	Temp.(°F)	Resistance(kΩ)	Temp.(°F)	Resistance(kΩ)	Temp.(°F)	Resistance(kΩ)
-2.2	138.1	68	18.75	138.2	3.848	208.4	1.071
-0.4	128.6	69.8	17.93	140	3.711	210.2	1.039
1.4	121.6	71.6	17.14	141.8	3.579	212	1.009
3.2	115	73.4	16.39	143.6	3.454	213.8	0.98
5	108.7	75.2	15.68	145.4	3.333	215.6	0.952
6.8	102.9	77	15	147.2	3.217	217.4	0.925
8.6	97.4	78.8	14.36	149	3.105	219.2	0.898
10.4	92.22	80.6	13.74	150.8	2.998	221	0.873
12.2	87.35	82.4	13.16	152.6	2.896	222.8	0.848
14	82.75	84.2	12.6	154.4	2.797	224.6	0.825
15.8	78.43	86	12.07	156.2	2.702	226.4	0.802
17.6	74.35	87.8	11.57	158	2.611	228.2	0.779
19.4	70.5	89.6	11.09	159.8	2.523	230	0.758
21.2	66.88	91.4	10.63	161.6	2.439	231.8	0.737
23	63.46	93.2	10.2	163.4	2.358	233.6	0.717
24.8	60.23	95	9.779	165.2	2.28	235.4	0.697
26.6	57.18	96.8	9.382	167	2.206	237.2	0.678
28.4	54.31	98.6	9.003	168.8	2.133	239	0.66
30.2	51.59	100.4	8.642	170.6	2.064	240.8	0.642
32	49.02	102.2	8.297	172.4	1.997	242.6	0.625
33.8	46.6	104	7.967	174.2	1.933	244.4	0.608
35.6	44.31	105.8	7.653	176	1.871	246.2	0.592
37.4	42.14	107.6	7.352	177.8	1.811	248	0.577
39.2	40.09	109.4	7.065	179.6	1.754	249.8	0.561
41	38.15	111.2	6.791	181.4	1.699	251.6	0.547
42.8	36.32	113	6.529	183.2	1.645	253.4	0.532
44.6	34.58	114.8	6.278	185	1.594	255.2	0.519
46.4	32.94	116.6	6.038	186.8	1.544	257	0.505
48.2	31.38	118.4	5.809	188.6	1.497	258.8	0.492
50	29.9	120.2	5.589	190.4	1.451	260.6	0.48
51.8	28.51	122	5.379	192.2	1.408	262.4	0.467
53.6	27.18	123.8	5.197	194	1.363	264.2	0.456
55.4	25.92	125.6	4.986	195.8	1.322	266	0.444
57.2	24.73	127.4	4.802	197.6	1.282	267.8	0.433
59	23.6	129.2	4.625	199.4	1.244	269.6	0.422
60.8	22.53	131	4.456	201.2	1.207	271.4	0.412
62.6	21.51	132.8	4.294	203	1.171	273.2	0.401
64.4	20.54	134.6	4.139	204.8	1.136	275	0.391
66.2	19.63	136.4	3.99	206.6	1.103	276.8	0.382

Resistance Table of Tube Temperature Sensors for Indoor and Outdoor (20K)

Temp.(°F)	Resistance(kΩ)		Temp.(°F)	Resistance(kΩ)		Temp.(°F)	Resistance(kΩ)		Temp.(°F)	Resistance(kΩ)
-2.2	181.4		68	25.01		138.2	5.13		208.4	1.427
-0.4	171.4		69.8	23.9		140	4.948		210.2	1.386
1.4	162.1		71.6	22.85		141.8	4.773		212	1.346
3.2	153.3		73.4	21.85		143.6	4.605		213.8	1.307
5	145		75.2	20.9		145.4	4.443		215.6	1.269
6.8	137.2		77	20		147.2	4.289		217.4	1.233
8.6	129.9		78.8	19.14		149	4.14		219.2	1.198
10.4	123		80.6	18.13		150.8	3.998		221	1.164
12.2	116.5		82.4	17.55		152.6	3.861		222.8	1.131
14	110.3		84.2	16.8		154.4	3.729		224.6	1.099
15.8	104.6		86	16.1		156.2	3.603		226.4	1.069
17.6	99.13		87.8	15.43		158	3.481		228.2	1.039
19.4	94		89.6	14.79		159.8	3.364		230	1.01
21.2	89.17		91.4	14.18		161.6	3.252		231.8	0.983
23	84.61		93.2	13.59		163.4	3.144		233.6	0.956
24.8	80.31		95	13.04		165.2	3.04		235.4	0.93
26.6	76.24		96.8	12.51		167	2.94		237.2	0.904
28.4	72.41		98.6	12		168.8	2.844		239	0.88
30.2	68.79		100.4	11.52		170.6	2.752		240.8	0.856
32	65.37		102.2	11.06		172.4	2.663		242.6	0.833
33.8	62.13		104	10.62		174.2	2.577		244.4	0.811
35.6	59.08		105.8	10.2		176	2.495		246.2	0.77
37.4	56.19		107.6	9.803		177.8	2.415		248	0.769
39.2	53.46		109.4	9.42		179.6	2.339		249.8	0.746
41	50.87		111.2	9.054		181.4	2.265		251.6	0.729
42.8	48.42		113	8.705		183.2	2.194		253.4	0.71
44.6	46.11		114.8	8.37		185	2.125		255.2	0.692
46.4	43.92		116.6	8.051		186.8	2.059		257	0.674
48.2	41.84		118.4	7.745		188.6	1.996		258.8	0.658
50	39.87		120.2	7.453		190.4	1.934		260.6	0.64
51.8	38.01		122	7.173		192.2	1.875		262.4	0.623
53.6	36.24		123.8	6.905		194	1.818		264.2	0.607
55.4	34.57		125.6	6.648		195.8	1.736		266	0.592
57.2	32.98		127.4	6.403		197.6	1.71		267.8	0.577
59	31.47		129.2	6.167		199.4	1.658		269.6	0.563
60.8	30.04		131	5.942		201.2	1.609		271.4	0.549
62.6	28.68		132.8	5.726		203	1.561		273.2	0.535
64.4	27.39		134.6	5.519		204.8	1.515		275	0.521
66.2	26.17		136.4	5.32		206.6	1.47		276.8	0.509

Resistance Table of Discharge Temperature Sensor for Outdoor(50K)

Temp.(°F)	Resistance(kΩ)		Temp.(°F)	Resistance(kΩ)		Temp.(°F)	Resistance(kΩ)		Temp.(°F)	Resistance(kΩ)
-20.2	853.5		50	98		120.2	18.34		190.4	4.754
-18.4	799.8		51.8	93.42		122	17.65		192.2	4.609
-16.6	750		53.6	89.07		123.8	16.99		194	4.469
-14.8	703.8		55.4	84.95		125.6	16.36		195.8	4.334
-13	660.8		57.2	81.05		127.4	15.75		197.6	4.204
-11.2	620.8		59	77.35		129.2	15.17		199.4	4.079
-9.4	580.6		60.8	73.83		131	14.62		201.2	3.958
-7.6	548.9		62.6	70.5		132.8	14.09		203	3.841
-5.8	516.6		64.4	67.34		134.6	13.58		204.8	3.728
-4	486.5		66.2	64.33		136.4	13.09		206.6	3.619
-2.2	458.3		68	61.48		138.2	12.62		208.4	3.514
-0.4	432		69.8	58.77		140	12.17		210.2	3.413
1.4	407.4		71.6	56.19		141.8	11.74		212	3.315
3.2	384.5		73.4	53.74		143.6	11.32		213.8	3.22
5	362.9		75.2	51.41		145.4	10.93		215.6	3.129
6.8	342.8		77	49.19		147.2	10.54		217.4	3.04
8.6	323.9		78.8	47.08		149	10.18		219.2	2.955
10.4	306.2		80.6	45.07		150.8	9.827		221	2.872
12.2	289.6		82.4	43.16		152.6	9.489		222.8	2.792
14	274		84.2	41.34		154.4	9.165		224.6	2.715
15.8	259.3		86	39.61		156.2	8.854		226.4	2.64
17.6	245.6		87.8	37.96		158	8.555		228.2	2.568
19.4	232.6		89.6	36.38		159.8	8.268		230	2.498
21.2	220.5		91.4	34.88		161.6	7.991		231.8	2.431
23	209		93.2	33.45		163.4	7.726		233.6	2.365
24.8	198.3		95	32.09		165.2	7.47		235.4	2.302
26.6	199.1		96.8	30.79		167	7.224		237.2	2.241
28.4	178.5		98.6	29.54		168.8	6.998		239	2.182
30.2	169.5		100.4	28.36		170.6	6.761		240.8	2.124
32	161		102.2	27.23		172.4	6.542		242.6	2.069
33.8	153		104	26.15		174.2	6.331		244.4	2.015
35.6	145.4		105.8	25.11		176	6.129		246.2	1.963
37.4	138.3		107.6	24.13		177.8	5.933		248	1.912
39.2	131.5		109.4	23.19		179.6	5.746		249.8	1.863
41	125.1		111.2	22.29		181.4	5.565		251.6	1.816
42.8	119.1		113	21.43		183.2	5.39		253.4	1.77
44.6	113.4		114.8	20.6		185	5.222		255.2	1.725
46.4	108		116.6	19.81		186.8	5.06		257	1.682
48.2	102.8		118.4	19.06		188.6	4.904		258.8	1.64



**TOSOT.COM**